City 200 EQ owner manual

MODEL EB-C200EQ | Owner information

The equipped model includes lights, mudguards, kickstand and a rear rack. Respect both the 25 kg rack limit and the bicycle's maximum total load. The rack is not approved for the JuniorSeat 22 child seat.

Online guide: agentcenter.team/demo/manuals/city-200-eq.html

Model specifications

Model code	EB-C200EQ
Intended use	Equipped city commuting and shopping
Frame	Aluminium
Gears	7 speed derailleur
Brakes	V brakes
Tyres	700 x 38 mm
Fork	Rigid fork
Weight	16.1 kg
Maximum total load, including bike, rider and cargo	130 kg
Sizing	S: indicative rider height 155 to 165 cm; M: indicative rider height 163 to 175 cm; L: indicative rider height 173 to 185 cm
Included lights	Yes
Included mudguards	Yes
Rear rack rating	25 kg
Battery	Not electric
Motor	Not electric

First use and fit

The shop states that bikes are assembled and checked for collection. Verify size, saddle position and safe operation with staff before riding. Rider-height guidance is indicative and cannot replace a fit check.

Before every ride

- Check that both brakes stop the bicycle reliably before joining traffic.
- Check the tyres for damage and inflation. Use the pressure range printed on the actual tyre sidewall, not an assumed universal value.
- Check that wheels and other visible fasteners are secure, with no unusual looseness or damage.
- Check the steering, saddle and controls for secure fit and comfortable reach.
- Check lights and reflectors where required for the conditions; check any carried load is secure.

If brakes, steering, wheels, folding joints or electrical parts appear unsafe, do not ride. Ask a qualified bicycle mechanic to inspect the bike.

Care and maintenance

- Clean with a soft cloth and gentle products; avoid pressure washing bearings and electrical connections.
- Keep the chain clean and lubricated appropriately, wiping off excess lubricant.
- Inspect tyres, brakes and drivetrain regularly, especially after wet rides or heavy use.
- After a crash, impact or suspected component damage, stop riding until the bicycle has been checked.
- Do not use unverified torque values, replacement parts or adjustments. Have a workshop confirm component-specific instructions.

Common issues

Brake feels weak or rubs	Do not ride until braking is safe. Ask a workshop to check pad wear, alignment and the correct brake type.
Gears skip or chain slips	Reduce load, stop safely, check for obvious damage and arrange a drivetrain adjustment.
Tyre repeatedly loses air	Inspect the tyre and inner tube or seek a puncture repair. Do not ride on a flat tyre.
Wheel, frame or steering damaged	Stop riding and have the affected parts examined before use.

Service and assistance

Use the Everyday Bikes servicing page for published service packages and pricing. Parts or additional work require a separate quote. For warranties and returns, consult the shop policies .

For unknown component specifications, including torque settings, tyre pressures, brake-fluid type and charging limits, ask qualified staff rather than using an invented setting.